

Bedienungsanleitung
für Plattformleiter

zulässige Belastung:
1500 N

Vor Benutzung Fahrwerk am Stützschenkel montieren .
Beim aufklappen darauf achten , daß die Verriegelung
der Scharnierstreben einrasten .

Vor besteigen der Plattformleiter die Feststeller
der Rollen betätigen .

Nach betreten der Plattform , Sicherheitsseil einhängen .

Instructions de servie pour
les échelles à plate-forme

charge limite :
1500 N (150 kg)

Avant toute utilisation , monter le mécanisme de
roulement sur les jambes de renforcement. Lors du
déploiement, veiller au verrouillage des articulations.

Avant de monter sur l'échelle à plate-forme , manoeuvrer
le mécanisme de freinage des roues . Après être monte
monté sur la plate-forme , fixer la corde de sécurité .

Operating instructions
for platform ladders

Admissible load:
1500 N (150 kg)

Install the running gear at the support leg prior to use .

When opening up , make sure that the catch of the hinge
struts is engaged . Always actuate the roller locking devices
before mounting the platform ladder . Attach the safety cable
after mounting the platform .

ZARGES Z600

www.zarges.de

Prüfung gemäß BGV D36

Nächste
Prüfung



Reg.Nr.



09/2004

L

41205



EN 131

Europäische Norm
European Standard
Norme Européenne



max.
150
kg



min.
1 m

