



ZARGES

Service Pack SP1 No.: 800428

Contents of Service Pack 1:

1. Shackle
2. Spring hook w/ energy-absorbing band element

Removal:

- Unscrew bolt (1) and pull it out from the band element.
- Take out shackle (2) from the slide mechanism.

Installation:

- Insert shackle (2) into the slide mechanism as shown. Apply some Loctite 2701 on the thread of the shackle.
- Insert bolt (1) through the shackle and energy-absorbing band element into the shackle thread and hand-tighten. Wipe off any emerged Loctite 2701.

ATTENTION The slide mechanism may only be used after the thread adhesive Loctite 2701 has dried.

Make sure to note the replacement of the energy-absorbing band element in the inspection book.

